SERVICE MANUAL

Quadro

Colour Television PAL/SECAM/BG

Models

14" CTV-37V10, 37V20, 37X10
(chasis 3011)

21" CTV-55V10, 55S10, 55X10, 55Z10

C UTION
Bef\be se\fing the ch4\p13sis, ead the "X-Ray Radiati\bn Pecauti
"Safety Pecauti\bn" and "P\bduct Safety | N\btice" \bn 2 \bf this manual

Contents

Safety Notice

SAFETY PRECAUTIONS

1: An isolation transformer should be connected in the power line between the receiver and the AC line when a service is performed on the primary of the converter transformer of the set.

2: Comply with all caution and safety-related notes provided on the cabinet back, inside the cabinet, on the chassis or the picture tube.

3: When replacing a chassis in the cabinet, always be certain that all the protective devices are installed properly,such as,control knobs, adjustment covers or shields, barriers,isolation resistor-capacitor networks etc.. Before returning any television to the customer,the service technician must be sure that it is completely safe to operate without danger of electrical shock.

X-RADIATION PRECAUTION

The primary source of X-RADIATION in television receiver is the picture tube. The picture tube is specially constructed to limit X-RADIATION emissions. For continued X-RADIATION protection, the replacement tube must be the same type as the original including suffix letter. Excessive high voltage may produce potentially hazardous X-RADIATION. To avoid such hazards, the high voltage must be maintained within specified limit. Refer to this service manual, high voltage adjustment for specific high voltage limit. If high voltage exceeds specfied limits, take necessary corrective action. Carefully follow the instructions for +B1 volt power supply adjustment, and high voltage check to maintain the high voltage within the specified limits.

PRODUCT SAFETY NOTICE

Product safety should be considered when a component replacement is made in any area of a receiver. Components indicated by mark ⚠ in the parts list and the schematic diagram designate components in which safety can be of special significance. It is particularly recommended that only parts designated on the parts list in this manual be used for component replacement designated by mark ⚠. No deviations from resistance wattage or voltage ratings may be made for replacement items designated by mark ⚠ .

Technical specification

FEATURES:

AC 90V - 260V 50/60Hz

MULTI SYSTEM: PAL BG/DK/I,SECAM BG/DK(OPTION),NTSC M(OPTION)

VOLTAGE SYNTHESISED TUNING SYSTEM

100/256 PROGRAMS MEMORY (OPTION)

BLUE BACK FUNCTION

120 MINUTES SLEEP TIMER

FULLAUTO PROGRAM

TIME ON

CLOCK ; CHILD LOCK

2 AV INPUT

GAME (OPTION)

8 PAGES TELETEXT (OPTION)

BLACK LEVEL STRETCH

PROGRAM VIEW FUNCTION

FOUR PICTURE MODE£ºMILD;COLORTUL; STANDARD ;CUSTOM;DYNAMIC

GENERAL SPECIFICATION:

1¡¢POWER CONSUMPTION£º 14 ¡å70W £¨MAX.£©
21 ¡å90 W £¨MAX.£©

2¡¢RECEIVE SYSTEM£º D/K ; I ; B/G ; M

3¡¢COLOUR SYSTEM: PAL/ SECAM/ NTSC

4¡¢VISION INTERMEDIATE FREQUENCY £º 38.9MHz

5¡¢INTER-CARRIER FREQUENCY: 4.5 MHz (M)
5.5 MHz (B/G)
6.0 MHz (I)
6.5 MHz (D/K)

6. CHROMA IF FREQUENCY PAL/NTSC: 34.47/35.32 MHz

7¡¢ANTENNA TYPE: DIN TYPE 75 OHM

8¡¢CHANNELS RECEIVING: VHF-1 A0;E2-E4;S1-S9 CH 46.25-161.25MHz
VHF-3 S10-S41; E5-E12 CH 168.25-463.25MHz
UHF E21-E69 CH 471.25-855.25MHz

9¡¢ TUNING SYSTEM£º VS TUNING

10¡¢ AV IN/OUT£º 2 AV IN+1 AV STEREO OUT

11¡¢AV IN/OUT SPECIFICATION£º VIDEO IN----1.0 ¡À0.2V_{P-P} 75 OHM
AUDIO IN----0-2V (r.m.s)
VIDEO OUT----1.0¡À0.2 V_{P-P} 75 OHM
AUDIO OUT----0-2V (r.m.s)

12¡¢OSD LANGUAGE£º ENGLISH

13¡¢AUDIO OUTPUT POWER: > 3W (1KHz, 0.5V INPUT , 10%THD)

14¡¢SAFETY AUTHENTICATION STANDARD£º CB

15¡¢LED INDICATORS£º POWER ON


16¡¢HAND SET TYPE £º HS08

17¡¢HAND SET POWER SUPLY £º BATTERY 3V £¨UM-3/R6/AA£©x2

18¡¢COLOUR PICTURE TUBE£º 14"£-21" 90 DEGREE TUBE


19¡¢REMOTE CONTROL DISTANCE: ¡Ý5 m

Chassis Block Diagram




IC Block Diagram

IC 201 (IIC BUS SINGLE CHIP VIF,SIF,VIDEO CHROMA) LA76810A/HA




IC Block Diagram

IC 402&IC 403(3W AUDIO OUTPUT)LA 4285




IC701 <TELETEXT> STV-5348




IC Block Diagram

IC301 <Vertical Output> LA7840




IC602 <POWER > STR-G6653




IC Block Diagram


IC202<SECAM> La7642



IC203,Q609,IC601&IC302<REGULATORS> L7800SERIES





D613<PHOTO TRANSISTOR> TLP621





1:ANODE
2:CATHODE
3:EMITTER
4:COLLECTOT


Transistor Mark




























Chassis wiring diagram





www.rtv-horvat-dj.hr
TUNER
IC001 LA8633XX
IC201 LA76810
IC402 LA4285
IC403 LA4285
STV5348 IC701
IC202 LA7642N
IC301 LA7840
IC401 TC4053
IC602 STR-6653
CN001 TO CONTROL BOARD
CN002 Service mode interface
AV O/P
AV1 I/P
AV2 I/P
CN601 220V/50HZ
1.Please attention all the components with sign
2.Please attention the heat GROUND with sign
3.There may be several change. All the data are only used for reference.
TITLE: 3Y11 SCHEMATIC DIAGRAM
SYSTEM: PAL/NTSC/SECAM 90-260V
P/N: 0502-A3Y111-01
DATE: 2003-03-11